BulbHead.com

HURRICANE™ SPIN DUSTER

Makes dusting fun and easy!

IMPORTANT SAFETY INSTRUCTIONS, READ AND FOLLOW ALL WARNINGS AND INSTRUCTIONS BEFORE USING THIS PRODUCT. INJURY CAN RESULT FROM IMPROPER USE. SAVE THESE INSTRUCTIONS.

⚠ WARNING

- For intended use only.
- Adult supervision required if used by children under 16.
- DO NOT use near water, or when duster head is wet after washing.
- DO NOT bend duster head or use force while dusting. If the duster head seems bent, DO NOT USE. Use of bent duster head may cause damage to power handle.
- Replace batteries when Hurricane™ Spin Duster becomes too slow, or it stops during use.
- Keep Hurricane™ Spin Duster away from hot surfaces.
- Not Dishwasher safe.
- Don't force duster head into extremely tight places.
- Do not mix old and new batteries.
- Do not mix alkaline, standard (carbon zinc) or rechargeable (nickel-cadmium) batteries.

⚠ WARNING

HARMFUL IF SWALLOWED.
KEEP BATTERIES AWAY FROM CHILDREN.

PRODUCT MAY VARY FROM IMAGES SHOWN

HOW TO CLEAN



Figure N

1. The duster head can be gently pulled off (Figure N) and shaken over a trash can or outdoors to release the dust.



Figure O

2. Alternatively, you may rinse the Duster Head Only! (Figure O) Let duster head air dry completely before next use or storing.

Figure P

3. Never expose the Power handle to water. Wipe clean with a damp cloth. (Figure P)

Manufactured for
TELEBrands.
Fairfield, NJ 07004
©2017 Telebrands
www.telebrands.com
Made in China

LIMITATION OF LIABILITY

Liability limited to the purchase price of this product. Telebrands Corp. shall not be liable for any incidental or consequential damages or any implied warranty on this product. Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you.